

Input: 110V-265V,50/60Hz

1. Power must be off before installation.

2.Installation/Repair only by authorised persons.

